

TECHNICAL SERVICE BULLETIN

73-G-5

NO.



Austin MG

April, 1973

SUBJECT:

PRE-DELIVERY INSPECTION
CALIFORNIA DEALERS ONLY
FORM # SER.73

MODELS:

ALL

The following operations have been checked prior to dealer delivery of all new vehicles:

Adjust as required

Dwell

Ignition timing advance and retard

Idle RPM and choke settings

Therefore, as indicated with a red asterisk under OSCILLOSCOPE CHECK on the attached Pre-Delivery Inspection Form #SER.73, these operations must be deferred until the 1,000 mile service.

REK



PRE-DELIVERY INSPECTION



SERIAL NO. _____ R/O NO. & DATE _____
ENGINE NO. _____ IGNITION KEY NO. _____
MAKE/MODEL _____ DOOR KEY NO. _____
OWNER _____ TRUNK KEY NO. _____
ADDRESS _____ COLOR/NO. _____ TRIM/NO. _____
TIRE MAKE/SIZE _____ Tire Type { Radial ☐ Cross Ply ☐
WhiteWall ☐ Black Wall ☐

INTERIOR

Check operation of and adjust as necessary

- ☐ All instruments
- ☐ All switches and controls
- ☐ All safety devices
- ☐ Clutch pedal
- ☐ Shift control
- ☐ Brake pedal
- ☐ Parking brake control
- ☐ Seats and mountings
- ☐ Seat belts and anchorage points
- ☐ Interior and exterior lighting
- ☐ All doors, hood, trunk, window controls and locks

UNDERCARRIAGE

Check for security, chafing, leaks and adjust as necessary

- ☐ Front suspension and steering
- ☐ Engine, transmission, drive line and rear axle
- ☐ Rear suspension
- ☐ Water, clutch, brake, fuel and vacuum hoses and pipes
- ☐ Exhaust system
- ☐ Adjust clutch and brake
- ☐ Grease all lubrication points
- ☐ Check all fluid levels

EXTERIOR

- ☐ Tighten all hub extensions and wheel nuts
- ☐ Check tires specification and adjust pressures including spare
- ☐ Check contents and operation of all tool kit items
- ☐ Check owners literature pack
- ☐ Install all items that were not fitted prior to shipment
- ☐ Check and adjust front wheel alignment
- ☐ Align head lamps
- ☐ Check fit of convertible/hardtop and tonneau covers

ENGINE COMPARTMENT

Check security, chafing, leaks and adjust as necessary

- ☐ All water, oil, fuel, freon, vacuum clutch and brake hoses and pipes
- ☐ All fluid levels
- ☐ Antifreeze protection to _____
- ☐ Battery specific gravity _____
- ☐ Electrical connections
- ☐ Manifolds
- ☐ All drive belts
- ☐ Lubricate choke and throttle linkage
- ☐ Charging system

OSCILLOSCOPE CHECK

* Adjust as required

- * ☐ Dwell
- ☐ Spark plugs (cruise and unload)
- * ☐ Ignition timing advance and retard
- * ☐ Idle RPM and choke settings
- ☐ CO _____% HC _____ P.P.M. readings

* State of
California dealers
refer to
service bulletin 73G5

ROAD TEST

Check for correct performance: ☐ Engine ☐ Drive Line
☐ Suspension ☐ Instrumentation ☐ Heating and Cooling
system ☐ Locate and rectify any rattles, vibrations or squeaks

FINAL PREPARATION

- ☐ Remove all flammable protective shipping materials
- ☐ Clean engine
- ☐ Vacuum and clean interior
- ☐ Wash and polish exterior
- ☐ Inspect interior and exterior for damage to upholstery,
floor coverings, paint, chrome and glass
- ☐ Place spare keys with owners literature pack

REMARKS: _____ ACCESSORIES TO BE FITTED: _____

I CERTIFY THAT THE VEHICLE DESCRIBED CONFORMS TO MANUFACTURER'S SPECIFICATIONS AND MEETS STATE
SAFETY AND EMISSION REQUIREMENTS

DEALER STAMP



MECHANIC _____

SERVICE MANAGER _____



PRE-DELIVERY INSPECTION



SERIAL NO. _____ R/O NO. & DATE _____
ENGINE NO. _____ IGNITION KEY NO. _____
MAKE/MODEL _____ DOOR KEY NO. _____
OWNER _____ TRUNK KEY NO. _____
ADDRESS _____ COLOR/NO. _____ TRIM/NO. _____
TIRE MAKE/SIZE _____ Tire { Radial ☐ Cross Ply ☐
Type { Whitewall ☐ Black Wall ☐

INTERIOR

Check operation of and adjust as necessary

- ☐ All instruments
- ☐ All switches and controls
- ☐ All safety devices
- ☐ Clutch pedal
- ☐ Shift control
- ☐ Brake pedal
- ☐ Parking brake control
- ☐ Seats and mountings
- ☐ Seat belts and anchorage points
- ☐ Interior and exterior lighting
- ☐ All doors, hood, trunk, window controls and locks

UNDERCARRIAGE

Check for security, chafing, leaks and adjust as necessary

- ☐ Front suspension and steering
- ☐ Engine, transmission, drive line and rear axle
- ☐ Rear suspension
- ☐ Water, clutch, brake, fuel and vacuum hoses and pipes
- ☐ Exhaust system
- ☐ Adjust clutch and brake
- ☐ Grease all lubrication points
- ☐ Check all fluid levels

EXTERIOR

- ☐ Tighten all hub extensions and wheel nuts
- ☐ Check tires specification and adjust pressures including spare
- ☐ Check contents and operation of all tool kit items
- ☐ Check owners literature pack
- ☐ Install all items that were not fitted prior to shipment
- ☐ Check and adjust front wheel alignment
- ☐ Align head lamps
- ☐ Check fit of convertible/hardtop and tonneau covers

ENGINE COMPARTMENT

Check security, chafing, leaks and adjust as necessary

- ☐ All water, oil, fuel, freon, vacuum clutch and brake hoses and pipes
- ☐ All fluid levels
- ☐ Antifreeze protection to
- ☐ Battery specific gravity
- ☐ Electrical connections
- ☐ Manifolds
- ☐ All drive belts
- ☐ Lubricate choke and throttle linkage
- ☐ Charging system

OSCILLOSCOPE CHECK

* Adjust as required

- * ☐ Dwell
- ☐ Spark plugs (cruise and unload)
- * ☐ Ignition timing advance and retard
- * ☐ Idle RPM and choke settings
- ☐ CO _____ % HC _____ P.P.M. readings

* State of
California dealers
refer to
service bulletin 73G5

ROAD TEST


Check for correct performance: ☐ Engine ☐ Drive Line
☐ Suspension ☐ Instrumentation ☐ Heating and Cooling
system ☐ Locate and rectify any rattles, vibrations or squeaks

FINAL PREPARATION

- ☐ Remove all flammable protective shipping materials
- ☐ Clean engine
- ☐ Vacuum and clean interior
- ☐ Wash and polish exterior
- ☐ Inspect interior and exterior for damage to upholstery, floor coverings, paint, chrome and glass
- ☐ Place spare keys with owners literature pack

REMARKS: _____ ACCESSORIES TO BE FITTED: _____

I CERTIFY THAT THE VEHICLE DESCRIBED CONFORMS TO MANUFACTURER'S SPECIFICATIONS AND MEETS STATE SAFETY AND EMISSION REQUIREMENTS



MECHANIC _____

SERVICE MANAGER _____