

73-H-1



## Austin MG

AUGUST, 1973

SUBJECT:

MODELS:

OPERATING INSTRUCTIONS -- MARINA AIR CONDITIONING

AUSTIN MARINA

In order to obtain maximum performance from the air conditioning unit fitted to the Austin Marina, it is essential that the controls are set at the proper position. The heater controls must be placed in the "Off" position; otherwise, ambient air will be continually fed into the vehicle and will, therefore, affect the efficiency of the unit.

An instruction card is to be included with the air conditioning kits in the future, a copy of which is reproduced below.

