

TECHNICAL SERVICE BULLETIN

NO.

74-G-2



Austin MG

SUBJECT:

SMITH INSTRUMENT TESTER
PART NO. 5001

MODELS:

ALL

If your Smith Instrument Tester is not operating properly, there is a possibility that the selector dial knob has been forced and is either slipping on the shaft or is in an improper relocated position so that it no longer points to the correct setting on the dial.

To correct this problem, remove the knob. Turn the shaft counter-clockwise until it stops. At this point reinstall the knob, pointing toward the "CE" on the "bimetal 10v" scale.

It may be necessary to file a flat on the shaft to coincide with the position of the allen screw with the knob pointing again to the "CE" of the "bimetal 10v" scale.

REK